



**BOLT THROUGH FIXING (ONE SIDE ONLY)**


**COMPONENTS**

Straight fixing offset handle




1

Wooden door / Frame door



3



**INSTRUCTIONS**

- 1) Measure the suitable distance and drill the holes 1-2mm larger than the bolt diameter. Refer to page 1 for the hole centres.

---

- 2) Partially screw the 80mm bolts into the brass reducers and put the brass reducers into the legs of the handle. Tighten up the grub screws on the legs of the handle to secure the brass reducers.  
Feed the plastic washer through the bolt.

---

- 3) Adjust the bolts to the length you require by threading them into the brass reducer. Leave enough thread on the bolt to secure with the securing caps.

---

- 4) Finally, fix the handle using the 2 threaded securing caps. Insert an Allen key into the side of the cap and tighten up firmly.

4

